

TENT INSTRUCTIONS

13' X 16'

AWNING



PACKING LIST:

1. TENT
2. ROPES (TIED TO TENT)
3. TWELVE STAKES (IN TENT BAG)
4. TWENTY-FIVE ANGLES - 10 FLOORS, 6 END TRUSS (3-WAY ANGLE WITH CAP) 9 CENTER TRUSS (4-WAY ANGLE)

SETUP DIRECTIONS:

1. CLEAR A FLAT AREA.
2. LAY A GROUND TARP (OPTIONAL BUT HELPS KEEP THE AREA CLEAN).
3. UNCLIP WIRE ROPE FROM RIDGE ANGLE PIECES.
4. ASSEMBLE RAFTER SYSTEM.
5. CLIP WIRE ROPE BACK TO RIDGE ANGLE PIECES.
6. INSTALL LEGS ON ONE SIDE (THIS KEEPS FRAME LOW ENOUGH TO INSTALL CANVAS).
7. PUT CANVAS ONTO FRAME SYSTEM (ZIPPER AND CORNERS SHOULD BE OPEN).
8. ADJUST CANVAS TO ALIGN WITH FRAME AND FASTEN STRAPS TO THE RIDGE POLES FROM INSIDE TENT.
9. INSTALL LEGS ON OTHER SIDE.
10. INSTALL POLES ALONG FLOOR (OPTIONAL).
11. VELCRO AND TIE ALL CORNERS.
12. ADJUST THE FRAME LOCATION PROPERLY, FASTEN ALL THE STRAPS TO THE FRAME.
13. TUCK GROUND CLOTH UNDER FLOOR POLES OR SIDE POLES OR SECURE DOWN WITH OTHER MATERIAL ON THE OUTSIDE.
14. STAKE, AND TIGHTEN ROPES (MAKE SURE THERE IS NOT TOO MUCH TENSION ON ZIPPER) – ALWAYS STAKE YOUR TENT DOWN EVEN WHEN SETTING UP YOUR TENT AT HOME.

MATERIALS NEEDED IF MAKING YOUR OWN FRAME:

TO COMPLETE YOUR FRAME, YOU WILL NEED 3/4" EMT (ELECTRICAL) CONDUIT THAT HAS AN OUTSIDE DIAMETER OF .922 INCHES. EMT CONDUIT CAN BE PURCHASED AT MOST HARDWARE STORES IN 10 FT SECTIONS. FLOOR PIECES (FRONT & BACK POLES AND 4 COMMON POLES) ARE NOT NECESSARY BUT HELP KEEP LEGS SQUARE. OFTEN INDIVIDUALS DO NOT DO THE FLOOR POLE ACROSS THE FRONT OF TENT.

NAME	QTY	LENGTH
RAFTER	10	7'-5"
FLOOR (FRONT & BACK)	4	6'-5 1/2"
FLOOR SPLICE *	2	2'
COMMON POLE	18	5'-4 1/2"
LEG	10	4'-9"

* PIPE SIZE SHOULD BE 1" CONDUIT. DRILL HOLE IN ONE SIDE OF SPLICE PIECE AND THROUGH ONE OF THE FLOOR POLES. BOLT CAN BE PLACED THROUGH HOLE. YOU MAY ALSO CHOOSE TO BUY A COUPLER FROM YOUR HARDWARE STORE.

HOW MANY POLES TO BUY:

IF YOU WOULD LIKE TO MINIMIZE WASTED MATERIAL AND CUT COSTS ON THE FRAME WE SUGGEST USING THE REMAINING 4'- 7 ½" POLE SCRAPS FROM THE COMMON POLES FOR YOUR LEGS. THIS WILL REDUCE THE WALL HEIGHT BY ABOUT 2 INCHES. YOU CAN ALSO USE TWO OF THESE 4'-7 ½" PIECES AS PART OF THE FLOOR THAT GOES IN THE FRONT AND BACK. IF YOU GO THIS ROUTE YOU WILL NEED TWO 8'- 4" POLES SECTIONS TO COMPLETE THE FRONT AND BACK FLOOR SECTION ALONG WITH A SPLICE PIECE. BUILDING YOUR COMPLETE FRAME IN THIS MANNER, INCLUDING THE AWNING WILL REQUIRE THIRTY 10' SECTIONS.

COMPLETE FRAME:

(10) POLES FOR RAFTERS

(18) POLES FOR COMMON (LATERAL) POLES - USE THE CUT PORTION FOR LEGS

(2) POLES FOR FLOOR (FRONT & BACK)

IF NO FLOOR POLES:

(10) POLES FOR RAFTERS

(12) POLES FOR COMMON - USE THE CUT PORTION FOR LEGS

5' WALLS (IF YOU DO NOT WANT YOUR WALLS 4'-10" BY USING THE CUT PORTION OF THE COMMON POLES)

(6) POLES FOR LEGS

ADDITIONAL FRAME INFORMATION:

ANGLE CONNECTIONS HAVE AN INSIDE DIAMETER OF 1" & 3/4" EMT HAS OUTSIDE DIAMETER OF .922". YOU MAY WANT TO COLOR CODE THE ENDS OF THE FRAME POLES WITH COLORED DUCT TAPE. THIS WILL HELP WITH ASSEMBLY AND REDUCE THE EXTRA SPACE BETWEEN THE POLES & THE ANGLE CONNECTORS.

IF YOU PURCHASED POLE CLIPS (HIGHLY RECOMMENDED), DRILL 1/4" HOLE 1-3/4" FROM THE END OF THE COMMON POLES. IF YOU ADD POLE CLIPS TO YOUR RAFTER POLES, DRILL 1/4" HOLE 1-1/4" FROM THE END OF THE POLE. MAKE SURE HOLES ON EACH END OF THE POLE ALIGN WITH EACH OTHER. DRILL ONE SIDE, INSTALL POLE CLIP, AND THEN CLIP IT INTO AN ANGLE CONNECTOR. THIS WILL HELP ALIGN THE HOLE LOCATION FOR THE OTHER SIDE. A DRILL PRESS AND PIPE LEVEL ALSO WORKS WELL. DO NOT INSTALL POLE CLIPS ON THE LEG POLES.

IF YOU PURCHASED PREMIUM ANGLES, YOU CUT YOUR PIPE TO THE SAME SIZE BUT ONLY BUY THE QUANTITY OF POLES AS OUTLINED UNDER IF NO FLOOR POLES.

ELK MOUNTAIN TENT FRAME:

YOU DO NOT NEED TO PURCHASE ANY CONDUIT, POLE CLIPS, OR POLE BAGS. YOU WILL HAVE (4) EXTRA RAFTER POLES. (2) OF THESE WILL HAVE A WELD SECTION ON THEM. THESE POLES ARE FOR THE FLOOR THAT GOES ALONG THE FRONT & BACK OF THE TENT. THE POLE WITHOUT THE WELD WILL SLIDE INTO THE WELDED POLE.



EXTRA METAL D-RINGS:

THERE ARE METAL D-RINGS THAT GO ALONG THE BOTTOM OF THE OUTSIDE OF YOUR TENT. THIS ALLOWS YOU TO STAKE DOWN THE WALLS. WE DO NOT SEND STAKES FOR THESE D-RINGS. THERE ARE ALSO D-RINGS ALONG THE RIDGE OF THE TENT. THIS IS FOR DOING A "NO FRAME" BACKCOUNTRY SETUP WHERE THE TENT HANGS FROM THE D-RINGS.

ATTENTION:


1. DO NOT DRAG THE TENT CLOTH WHEN ASSEMBLING AND DISMANTLING. THIS MAY DAMAGE THE CANVAS.
2. WHEN WINTER CAMPING, CLEAR OFF SNOW BUILD UP. FRAMES ARE NOT DESIGNED TO HANDLE SNOW LOADS.
3. ONLY USE A WOOD STOVE PER THE MANUFACTURERS RECOMMENDATION. ALWAYS HAVE A SPARK ARRESTOR. SPARKS WILL BURN A HOLE IN ANY TENT CANVAS.
4. CLEAN & DRY TENT BEFORE STORING.
5. WE HIGHLY SUGGEST YOU SETUP THE TENT FOR THE FIRST TIME AT HOME BEFORE GOING INTO THE MOUNTAINS TO ASSURE YOU HAVE ALL THE PARTS NEEDED.

STOVE JACK:

CUT STOVE JACK TO REQUIRED SIZE. A RUBBER GASKET IS NOT NEEDED; THE MATERIAL IS HEAT RESISTANT. YOU MAY WANT TO CUT THE HOLE 1/4" LARGER THAN THE STOVE PIPE TO ALLOW THE TENT TO MOVE WITHOUT PULLING ON THE PIPE.


A COPY OF THESE INSTRUCTIONS ALONG WITH SOME VIDEOS CAN BE FOUND AT:

<http://www.elkmountaintents.com/wall-tent-setup/>




13' X 16' FLOOR SYSTEM


NOTE:
SEE PAGE 6 FOR ANGLE
CONNECTION DETAILS.




13'x16' FRAME WITH AWNING




(A)




(B)



(C)




(C)




(D)

NOTE:
THIS ANGLE CONNECTOR IS
ALSO USED FOR AWNING
TO TENT ATTACHMENT



(D)



(E)

ANGLE TO POLE CONNECTION DETAILS